

## Complete Gas Injection Kit

### Complete Gas Injection Kit for the Extrima, Ex-certified Hydrogen Leak Detector

The Complete Gas Injection Kit is an accessory to the Extrima, Ex-certified Hydrogen Leak detector, for injecting tracer gas into fuel leaks during maintenance of aircrafts. The kit includes a complete set of accessories that you need for efficient leak detection in many different kind of situations, all delivered in a smart and heavy-duty transport case. The equipment includes Injection Pads, Injection Fix Kit and Injection Panel which incorporates a certified leak for calibration of the detector.

#### Accessories Included (or offered separately) in the Complete Gas Injection Kit:

##### **Injection Pads**

During leak detection the Injection Pads are used to inject tracer gas via the leak exit point. When the gas has been injected, the Ex-certified leak detector Extrima is recommended for pin-pointing the leak on the fuel system. The pads are available in sizes Small (60 mm) and Large (150 mm).

##### **Injection Fix Kit**

When fuel leaks are found in tricky places, the Injection Fix Kit allows for adapting the injection tool to a specific situation. The kit includes PVC tubes, cutter, aluminum tape, injection plug, mylar film and sealant tape.

##### **Injection Panel**

The Injection Panel is the complete Gas Injection Kit without the Injection Pads and the Injection Fix Kit.



## LEISTUNGEN

- Makes back tracing aircraft fuel leaks controlled and efficient
- Can be operated by one operator
- Includes all you need between the tracer gas bottle and the leak
- Helps keep your detector calibrated
- Delivered in a durable and heavy-duty transport case

## MERKMALE

---

- Accessory to the Extrima, Ex-certified Hydrogen Leak Detector
- Includes Injection Pads which are used to inject tracer gas via the leak exit point
- Includes the Injection Fix Kit, the easiest way to find leaks when they are located on uneven surfaces
- Includes the Injection Panel, for easy tracer gas injection from bottle to Injection Pads, check the pressure and that your instrument is calibrated
- The Injection Pads, Injection Fix Kit and the Injection Panel can also be delivered separately

## BESTELLINFORMATIONEN

---

Typ	Complete Gas Injection Kit
Injektions-Fix-Kit, zur Injektion von Prüfgas bei Lecks auf ungleichmäßigen Oberflächen	590-618
Injektionspads, groß, 150 mm, 10 Stck. (zur Befüllung von Gasbehältern mit Prüfgas)	590-616
Injektionspads, klein, 60 mm, 10 Stck. (zur Befüllung von Gasbehältern mit Prüfgas)	590-615
Injektionspanel zur einfachen Gasinjektion von der Flasche auf das Injektionspad	590-619
Komplettes Gasinjektionskit (inkl. Injektionspanel, Injektions-Fix-Kit und Injektionspads)	590-621



[www.inficon.com](http://www.inficon.com)    [reachus@inficon.com](mailto:reachus@inficon.com)

Aufgrund laufender Produktverbesserungen können sich Spezifikationen ohne vorherige Bekanntmachung ändern.  
RateWatcher ist eine eingetragene Marke von INFICON. Alle anderen Marken sind das Eigentum ihrer jeweiligen Eigentümer.

(2013-05)    © 2013 INFICON