



## Complete Gas Injection Kit

### Complete Gas Injection Kit for the Extrima, Ex-certified Hydrogen Leak Detector

The Complete Gas Injection Kit is an accessory to the Extrima, Ex-certified Hydrogen Leak detector, for injecting tracer gas into fuel leaks during maintenance of aircrafts. The kit includes a complete set of accessories that you need for efficient leak detection in many different kind of situations, all delivered in a smart and heavy-duty transport case. The equipment includes Injection Pads, Injection Fix Kit and Injection Panel which incorporates a certified leak for calibration of the detector.

#### Accessories Included (or offered separately) in the Complete Gas Injection Kit:

##### **Injection Pads**

During leak detection the Injection Pads are used to inject tracer gas via the leak exit point. When the gas has been injected, the Ex-certified leak detector Extrima is recommended for pin-pointing the leak on the fuel system. The pads are available in sizes Small (60 mm) and Large (150 mm).

##### **Injection Fix Kit**

When fuel leaks are found in tricky places, the Injection Fix Kit allows for adapting the injection tool to a specific situation. The kit includes PVC tubes, cutter, aluminum tape, injection plug, mylar film and sealant tape.

##### **Injection Panel**

The Injection Panel is the complete Gas Injection Kit without the Injection Pads and the Injection Fix Kit.



#### **BENEFITS**

- Makes back tracing aircraft fuel leaks controlled and efficient
- Can be operated by one operator
- Includes all you need between the tracer gas bottle and the leak
- Helps keep your detector calibrated
- Delivered in a durable and heavy-duty transport case

## FEATURES

---

- Accessory to the Extrima, Ex-certified Hydrogen Leak Detector
- Includes Injection Pads which are used to inject tracer gas via the leak exit point
- Includes the Injection Fix Kit, the easiest way to find leaks when they are located on uneven surfaces
- Includes the Injection Panel, for easy tracer gas injection from bottle to Injection Pads, check the pressure and that your instrument is calibrated
- The Injection Pads, Injection Fix Kit and the Injection Panel can also be delivered separately

## ORDERING INFORMATION

---

Type	Complete Gas Injection Kit
Complete Gas Injection Kit (incl. Injection Panel, Injection Fix Kit and Injection Pads)	590-621
Injection Fix Kit, for injecting tracer gas to leaks on uneven surfaces	590-618
Injection Pads Large, 150 mm, 10 pcs (for filling tracer gas into fuel tanks)	590-616
Injection Pads Small, 60 mm, 10 pcs (for filling tracer gas into fuel tanks)	590-615
Injection Panel, for easy gas injection from bottle to Injection Pad	590-619



[www.inficon.com](http://www.inficon.com)    [reachus@inficon.com](mailto:reachus@inficon.com)

Due to our continuing program of product improvements, specifications are subject to change without notice.  
RateWatcher is a trademark of INFICON. All other trademarks are the property of their respective owners.

(2013-05)    © 2013 INFICON