

Complete Gas Injection Kit

Complete Gas Injection Kit for the Extrima, Ex-certified Hydrogen Leak Detector

The Complete Gas Injection Kit is an accessory to the Extrima, Ex-certified Hydrogen Leak detector, for injecting tracer gas into fuel leaks during maintenance of aircrafts. The kit includes a complete set of accessories that you need for efficient leak detection in many different kind of situations, all delivered in a smart and heavy-duty transport case. The equipment includes Injection Pads, Injection Fix Kit and Injection Panel which incorporates a certified leak for calibration of the detector.

Accessories Included (or offered separately) in the Complete Gas Injection Kit:

Injection Pads

During leak detection the Injection Pads are used to inject tracer gas via the leak exit point. When the gas has been injected, the Ex-certified leak detector Extrima is recommended for pin-pointing the leak on the fuel system. The pads are available in sizes Small (60 mm) and Large (150 mm).

Injection Fix Kit

When fuel leaks are found in tricky places, the Injection Fix Kit allows for adapting the injection tool to a specific situation. The kit includes PVC tubes, cutter, aluminum tape, injection plug, mylar film and sealant tape.

Injection Panel

The Injection Panel is the complete Gas Injection Kit without the Injection Pads and the Injection Fix Kit.



BENEFICIOS

- Makes back tracing aircraft fuel leaks controlled and efficient
- Can be operated by one operator
- Includes all you need between the tracer gas bottle and the leak
- Helps keep your detector calibrated
- Delivered in a durable and heavy-duty transport case

CARACTERÍSTICAS

- Accessory to the Extrima, Ex-certified Hydrogen Leak Detector
- Includes Injection Pads which are used to inject tracer gas via the leak exit point
- Includes the Injection Fix Kit, the easiest way to find leaks when they are located on uneven surfaces
- Includes the Injection Panel, for easy tracer gas injection from bottle to Injection Pads, check the pressure and that your instrument is calibrated
- The Injection Pads, Injection Fix Kit and the Injection Panel can also be delivered separately

INFORMACIÓN DEL PEDIDO

Tipo	Complete Gas Injection Kit
Complete Gas Injection Kit	590-621
Injection Fix Kit	590-618
Injection Pads Large, 150 mm	590-616
Injection Pads Small, 60 mm	590-615
Injection Panel	590-619



www.inficon.com reachus@inficon.com

Debido a nuestro programa continuo de mejoras en los productos, las especificaciones están sujetas a modificaciones sin previo aviso. RateWatcher es una marca comercial de INFICON. El resto de marcas comerciales son propiedad de sus respectivos propietarios.

(2013-05) © 2013 INFICON