

Visionary Sensor Technology



Edge[™] CDG045D2 and CDG100D2 High Precision Vacuum Gauge

Hot Inside - Small Outside

Edge CDG045D2 and CDG100D2 Vacuum Gauges



INFICON Edge Capacitance Diaphragm Gauge is a highly accurate vacuum measurement instrument designed for harsh manufacturing environments. The proven temperature controlled, corrosion resistant, ultra-pure ceramic sensor provides superior span stability over many years paired with state-of-the-art zero stability. Edge comes with the INFICON patented unique sensor shield which protects the gauge from undesired process by-products.

Advanced electronics offer a wide range of configurable signal conditioning for all applications and optional EtherCAT fieldbus interface.

The innovative heating concept enables a cool to the touch surface and saves valuable tool space. INFICON Edge is the smallest vacuum measurement instrument of its kind.

Typical applications

- CVD, Etch, PVD
- Analytical applications
- · General high temperature vacuum applications



Fully ceramic sensor

Bonded ceramic structure combined with digital signal processing provides superior measurement performance.



Span stability Any mounting orientation









INFICON

EDGE ADVANTAGES AT A GLANCE

- · Low tool space required Smallest instrument in class
- Flexible integration EtherCAT fieldbus
- Long lifetime Proven ceramic sensor

DIAG

< ERO

• Forget recalibration - 90 ppm/year full scale stability

RUN



4 A

NFICON



NFICON

EXCELLENT CUSTOMER SUPPORT IS A COMMITMENT

INFICON provides a global network of sales and service centers. These centers are staffed with local service and application experts who can assist you in choosing the best solution for your individual product application and provide fast support if service is needed.



CHINA

INFICON Ltd. Beijing Phone: +86.10.6590.0164 E-mail: reach.china@inficon.com

INDIA

INFICON PVT. Ltd. Pune Phone: +91.20.4120.4854 E-mail: reach.india@inficon.com

JAPAN INFICON Co. Ltd.

Yokohama-shi, Kanagawa-ken Phone: +81.45.471.3328 E-mail: reach.japan@inficon.com

KOREA INFICON Ltd.

Kyunggi-do Phone: +82.31.783.2942 E-mail: reach.korea@inficon.com

SINGAPORE and AUSTRALIA

INFICON PTE Ltd. Singapore Phone: +65.6631.0300 E-mail: reach.singapore@inficon.com

TAIWAN

INFICON Co. Ltd. Chupei City Phone: +886.3.552.5828 E-mail: reach.taiwan@inficon.com

Americas

INFICON Inc. East Syracuse, NY Phone: +1.315.434.1100 E-mail: reach.us@inficon.com



Europe, Middle East

Phone: +49.221.567.881.00 E-mail: reach.germany@inficon.com

inficon.com reachus@inficon.com twitter.com/inficon Due to our continuing program of product improvements, specifications are subject to change without notice. tibc49e1 ©2013 INFICON