

TYPE EVPP-xxx-T2A



Portable vacuum system which in the transport frame integrated 2 litre tank and automatic vacuum level control unit. The vacuum level control unit can be set at vacuum levels between 100 to 1000 mbar and also the hysteresis is adjustable. This unit can hold different dry piston vacuum pumps. As the dimensions and the weight of this unit are low it is a very easy unit to take to different working locations where there is a temporary need for vacuum.

Technical Data		TYPE EVPP-xxx-T2A	
		EVPP-D06-T2A	EVPP-D07-T2A
Nominal displacement	l/m	102	135
Tank volume	ltr	2	2
Ultimate vacuum/pressure	bar	-0,92	-0,92
Motor power	W	245	380
Weight	kg	18,0	18,5
Connections	G(BSP)	1/4"	1/4"
Dimensions LxWxH	mm	430x350x430	430x350x430

Technical Data		TYPE EVPP-D02-T2A-DC
Nominal displacement	l/m	102
Tank volume	ltr	2
Ultimate vacuum/pressure	bar	-0,92
Motor power	W	210
Weight	kg	17,0
Connections	G(BSP)	1/4"
Dimensions LxWxH	mm	430x350x430

Ordering Information	EVPP-xxx-T2A
EVPP-D06-T2A (230V, 50Hz)	671.001
EVPP-D07-T2A (230V, 50Hz)	671.002
EVPP-D02-T2A-12VDC (12V, DC)	671.103
EVPP-D02-T2A-24VDC (24V, DC)	671.203
Adjustable vacuum Switch (mech.)	119.800
Adjustable vacuum Switch (digital)	119.820
Damper G1/4"	670.900
Accessories	See accessories page